



Processor Support Guide



Processor	Processor Family	LinuxLink
MCP855	FS-PQ-I	FS-MPC-885
MCP860		
MCP870		
MCP875		
MCP880		
MCP885		
MCP8250	FS-PQ-II	FS-MPC-8260
MCP8255		
MCP8260		
MCP8264		
MCP8265		
MCP8266		
MCP8247	FS-PQ-II	FS-MPC-8272
MCP8248		
MCP8271		
MCP8272		
MPC8270	FS-PQ-II	FS-MPC-8280
MPC8275		
MPC8280		
MPC8349	FS-PQ-II-PRO	FS-MPC-8349
MPC8541E	FS-PQ-III	FS-MPC-8555
MPC8555E		
MPC8540	FS-PQ-III	FS-MPC-8560
MPC8560		
MPC750	FS-MPC-7xx	FS-MPC-750
MPC755		
MPC8245		
MPC7455	FS-MPC-74xx	FS-MPC-7450
MPC7457		
MPC7447		
IBM750FX	IBM-7xx	IBM-750
IBM750GX		
IBM 970FX	IBM-9xx	IBM-970
AMCC440GX	AMCC-44x-G	AMCC-440-G
AMCC440GP		
AMCC-44x-E	AMCC 440E Series	AMCC-440-E
ARM 920T	ARM-9	ARM-9
ARM926EJ-S	ARM-9E	ARM-9E
FS iMX 21	FS-iMX-21	FS-iMX21
IOP321	Intel-IOP	INTEL-IOP321
80219	Intel-IOP	INTEL-80219
IOP331	Intel-IOP	INTEL-IOP331
IOP332	Intel-IOP	INTEL-IOP332
IXP425	Intel-IXP-425	INTEL-IXP425
MIPS4Kc	MIPS-32	MIPS-24k
MIPS4KEc		
MIPS24Kc		
Pentium	IA-32	INTEL-Pentium